



DELIGHTCOLOR IMAGITECH

Item #(For Epson)	Color	Compatibility
DL-E-007/008/009	Black/3-Color/5-Color	Epson Stylus Photo 1270,1280,780,785,870,,890,900
DL-E-017/018	Black/3-Color	Epson 1000 ICS, Epson Stylus Color 777,777i
DL-E-019/020	Black/3-Color	Epson Stylus Color 83,880
DL-E-026/027	Black/5-Color	Epson Stylus Photo 820,925
DL-E-028/029	Black/3-Color	Epson Stylus C60
DL-E-036/037	Black/3-Color	Epson Stylus C42UX,C44UX
DL-E-038/039	Black/3-Color	Epson Stylus CX1500v
DL-E-040/041	Black/3-Color	Epson Stylus C62, Epson Stylus CX3200
DL-E-050	Black	Epson Stylus Photo 1200,700, Epson Stylus Color 400,500,600
DL-E-051/052	Black/3-Color	Epson Stylus Color 740,740i,760,800,850,850N,850Ne,860, 1160,1520
DL-E-0321/2/3/4	B/C/M/Y	Epson Stylus C80,C82, Epson Stylus CX5200,5400
DL-E-0331/2/3/4/5/6	B/C/M/Y/LC/LM	Epson Stylus Photo 960
DL-E-0422/3/4	C/M/Y	Epson Stylus C82,C82N,C82WN, Epson Stylus CX5200,5400
DL-E-0431	Black	Epson Stylus C84,C84N,C84WN,C86,C86, Epson Stylus CX6400,6600
DL-E-0441/2/3/4	B/C/M/Y	Epson Stylus C64,C66,C84,C86, Epson Stylus CX4600,6400,6600
DL-E-0461	Black	Epson Stylus C63
DL-E-0472/3/4	C/M/Y	Epson Stylus C63
DL-E-0481/2/3/4/5/6	B/C/M/Y/LC/LM	Epson Stylus Photo RX500,600,620,
DL-E-0551/2/3/4	B/C/M/Y	Epson Stylus Photo R240,RX420,RX425,RX520
DL-E-0601/2/3/4	B/C/M/Y	Epson Stylus C68,C88,C88+, Epson Stylus CX3800,3810,4200,4800,5800F,7800
DL-E-0611/2/3/4	B/C/M/Y	Epson Stylus D68PE,D88,D88plus,DX3800,DX3850,DX4200,DX4250,DX4800 ,DX4850
DL-E-0631/2/3/4	B/C/M/Y	Epson Stylus C67,CX3700,CX4700
DL-E-0691/2/3/4	B/C/M/Y	Epson Stylus CX5000,6000,7000F,7400,8400,9400FAX
DL-E-0711/2/3/4/5/6	B/C/M/Y	Epson Stylus D78,D92,D120,DX4000,DX5000,DX6000,DX7400,DX8400
DL-E-0731/2/3/4/5/6	B/C/M/Y	Epson Stylus CX5900,CX6900F
DL-E-0771/2/3/4/5/6	B/C/M/Y	Epson Stylus Photo RX580,595,680, Epson Stylus Photo R260,R280,R380
DL-E-0791/2/3/4/5/6	B/C/M/Y	Epson Stylus Photo 1400
DL-E-0801/2/3/4/5/6	B/C/M/Y	Epson Stylus R285,RX585,RX685, Epson Stylus Photo R265,R360,RX560
DL-E-0811/2/3/4/5/6	B/C/M/Y	Epson Stylus Photo R270,RX590,RX690
DL-E-0821/2/3/4/5/6	B/C/M/Y	Epson Stylus Photo R270,RX590,RX690
DL-E-0881/2/3/4	B/C/M/Y	Epson Stylus CX4400,4450

Item #(For Canon)	Color	Compatibility
DL-C-05	3-Color	BJC-150/210/210j/210s/210sp/240/250/255sp/1000
DL-C-20	Black	BJC-400j/2000Series/4000Series/5000Series
DL-C-BX2	Black	FAX-B320/B340/B310/B320F/B340F/B360/B400
DL-C-BX3	Black	FAX-B100/B110
DL-C-PG40	Black	PIXMA iP1600,iP1700,iP1800,iP2600,MP140,MP210,MP450,MX300
DL-C-CL41	3-Color	PIXMA iP1600,iP1700,iP1800,iP2600,MP140,MP210,MP450,MX300
DL-C-PGI5BK	Black	PIXMA iP3300,iP3500,iP4200,iP4300,iP4500,iP5200,MP500,MP600,MP800,MP950
DL-C-CLI8BK/C/M/Y	Black	PIXMA iP4200,iP4300,iP4500,iP5200,MP500,MP600,MP800,MP950,Pro9000

Item #(For HP)	Color	Compatibility
DL-H-15	Black	HP Deskjet 3810/3816/3820/3822
DL-H-21	Black	HP Deskjet 3920/3930/3940/ PCS 1410/1410v/1410xi/1417
DL-H-22	3-Color	HP Deskjet 3920/2930/3940 PSC 1410/1410v/1410xi/1417
DL-H-23	3-Color	Deskjet 710C/720C/810C/830C/880C/890C/1100c
DL-H-26	Black	Desk Writer/500C/540C/550C/560C/Designjet 200/220/600
DL-H-27	Black	Deskjet 3320C/3400C/3500C/3600C/3740C/3840C
DL-H-28	3-Color	Deskjet 5551/5550/3320/3420/3425; Photosmart 7150/7350/7550
DL-H-45	Black	DeskJet 700C/800C/900C/1000C/1100C/1200C/1600C PhotoSmart P1000/1215
DL-H-49	3-Color	Deskjet 500C/520C/570C/580C/590C/600C/610C/630C/660C
DL-H-56	Black	HP Deskjet 5150/5510/5550/7350/7960
DL-H-57	3-Color	HP Deskjet 5150/5510/5550/7350/7960
DL-H-78	3-Color	DeskJet 920C/930C/940C/950C/960C/970C/980C/990C/1180C/1220C
DL-H-338	Black	Europe Countries:Deskjet5740/6540/6840series/8450
DL-H-343	3-Color	Europe Countries:Deskjet5740/6540/6840series/8450
DL-H-339	Black	Europe Countries:Deskjet5740/6540/6840series/8450
DL-H-344	3-Color	Europe Countries:Deskjet5740/6540/6840series/8450

Item #(For Lexmark)	Color	Compatibility
DL-L-70	Black	Lexmark 3200,5000,5700,5770,7000,7200,7200V,Z42,Z43,Z45,Z51,Z52,Z53,Z54
DL-L-80	3-Color	Lexmark 3200,5000,5700,5770,7000,7200,7200V, Lexmark Optra Color 40,45,45n
DL-L-50	Black	Lexmark P707,Z12,Z22,Z32,Z705,Z715
DL-L-20	3-Color	Lexmark P707,Z42,Z43,Z45,Z51,Z52,Z53,Z54,Z705,Z715
DL-L-60	3-Color	Lexmark Z12,Z22
DL-L-16	Black	Lexmark Z13,Z23,Z25,Z33,Z35,Z515,Z605,Z611,Z615,Z645
DL-L-26	3-Color	Lexmark Z13,Z23,Z25,Z33,Z35,Z515,Z605,Z611,Z615,Z645
DL-L-32	Black	Lexmark Z816,P915
DL-L-33	3-Color	Lexmark Z816,P315,P450,P915
DL-L-34	Black	Lexmark Z845
DL-L-35	3-Color	Lexmark Z845
DL-L-120	3-Color	Lexmark Z42/Z43/Z45/Z51/Z52/Z53/Z705/Z715/P707/X73/X83/X85/X125

